

Alnor® HVAC Handbook



Alnor[®] HVAC Handbook

A Practical Guide to Performance
Measurements in Mechanical Heating,
Ventilating and Air Conditioning Systems

Contents

Contents	i
-----------------------	----------

Introduction	1
---------------------------	----------

General	1
HVAC Systems, Comfort, and Energy Management.....	1
TAB: Testing, Adjusting, and Balancing	2
Certification and Clean-air Measurements	2
IAQ.....	3
Combustion Analysis	3

Measurement Instrumentation	4
--	----------

Capture Hoods.....	4
Mechanical (Analog) Capture Hoods	4
Digital Capture Hoods	5
Digital Capture Hoods with Differential Pressure Sensor.....	6
Thermo-Anemometers (Hot-Wires)	6
Basic Thermo-Anemometers.....	7
Thermo-Anemometers with Mathematical Calculations.....	7
Comprehensive Thermo-Anemometers	7
Rotating Vane Anemometers.....	8
Mechanical Rotating Vanes.....	8
Digital Rotating Vanes.....	8
Deflecting Vane (Swinging Vane) Anemometers	9
6000AP Velometer	10
Velometer Jr	10
Manometers	10
Inclined Gauge Manometer	11
Digital Micromanometer	11
Digital Auto-Zeroing Micromanometer.....	12
Pitot Tube	13
Hydronics	14
Mechanical Gauges.....	14
Digital Hydronic Manometers	15
IAQ: Ventilation and Carbon Dioxide.....	15
Basic CO ₂ Instrumentation.....	15
CO ₂ and Comfort Instrumentation	16
Thermo-Hygrometers: Temperature and Relative Humidity.....	16
Basic Thermo-Hygrometers	17
Datalogging Thermo-Hygrometers	17
Manual Gas Measurements (Combustion System).....	17
Portable Electronic Combustion Analysis Instruments	18
Continuous Emission Monitors	18

Measurement Basics	19
---------------------------------	-----------

HVAC System Performance	19
Measuring Air Velocity and Air Volume at Supply Grilles/Diffusers	19
Nonuniform Flow Corrections.....	20
Static Pressure Measurement.....	21
Exhaust Grille Measurements	21
Duct Traversing: Low to High Velocities and at High Air Temperatures	22
Measuring Air Velocity in Open Areas.....	23

Testing and Certification	23
Differential Pressure Measurement Between Two Rooms or Areas.....	23
Spray Booths	24
Laboratory Hoods	24
Unit Ventilators	25
Measuring Slot Velocities	25
Clean Room Testing and Certification	26
Thermal Comfort and IAQ.....	26
Air Temperature Measurement	26
Relative Humidity Measurement	27
CO ₂ Measurements	27
Taking Gas Samples	28
Temperature and Draft Measurements	28
Soot Measurements.....	29
Appendixes	30
Appendix A—Performing a Duct Traverse	30
Where to Take the Measurement.....	30
Traversing a Round Duct	30
Traversing a Square Duct	32
Appendix B—Capture Hood Flow Resistance.....	33
Appendix C—Characterizing a Capture Hood to an Outlet Using a Correction Factor.....	34
Appendix D—Determining the Percentage of Outside Air Using Either Temperature or CO ₂ Measurements	36
Appendix E—Air Changes per Hour (ACH).....	38
Appendix F—Thermal Comfort: Temperature and Humidity	39
Appendix G—Density Correction.....	40
Density Correction for Thermo-Anemometers	40
Density Correction for Pressure Based Manometers or Deflecting Vane Anemometers	40
Appendix H—Useful Calculations.....	43
Total Pressure Formula.....	43
Converting Velocity Pressure to fpm.....	43
Air Flow Formulas	43
Area Formulas.....	43
Subtracting Obstructions From Area.....	44
Hydronic Equations	44
Appendix I—Common HVAC Blueprint Symbols	45
Appendix J—Typical HVAC System Showing Some Measurement Locations.....	46
Appendix K—Fuel Specifications and Energy Units.....	47
Fuel Specifications	47
Energy Units.....	47
Appendix L—Sample Boiler Tune-Up Procedure.....	49
Tune-up Procedure—Using an Electronic Combustion Analyzer	49
Glossary	51
References	53
Notes	54

Introduction

General

This handbook has been developed as a tool to assist you in the field and also as a training aid for newer technicians. The contents cover a wide variety of heating and air conditioning ventilation measurement applications and technologies.

Air measurements are a critical concern for a wide range of applications. Facility Managers have long recognized the value of air readings in ensuring the balance, efficiency, and cost effectiveness of a facility's heating, cooling, and ventilation systems. Air flow, temperature, and humidity affect occupant comfort, productivity, and physical health in hospitals, schools, commercial, and industrial facilities. Indoor Air Quality (IAQ) and thermal comfort have become increasingly important in promoting healthy and comfortable work environments in today's workplace.

HVAC Systems, Comfort, and Energy Management

Energy management is central to all building functions. HVAC systems typically account for over one-third of a facility's energy consumption, so it is imperative to properly manage the operation of HVAC systems to ensure economical operation while providing a comfortable, safe environment for occupants.

One group of tools widely recommended for HVAC system performance testing, verification, and energy audits are test and balance instrumentation. These tools are designed to measure air velocity, air volume, temperature, humidity, CO₂, and noise level from heating and air conditioning ventilation ducts to identify problems with airflows, outside air mixing, system balancing, indoor air quality, and occupant comfort. Test instruments provide a means to properly measure and document key HVAC parameters by identifying potential energy conservation measures that can significantly reduce facility energy expenditures.

Measurement tools will help assess the operating efficiencies and discover system problems such as clogged filters, dirty coils, inoperative dampers, improperly programmed building control system loops, excessive outside air, defective thermostats and sensors, and simultaneous heating and cooling—all of which contribute to inefficient HVAC system operation, wasting considerable money. Information from testing is used in building and HVAC system commissioning reports, used to benchmark system performance, and to identify areas of energy waste.

Today's HVAC systems must be energy efficient, satisfy stringent indoor air quality and comfort expectations, and still be designed/constructed within tight budgets. System designs meeting these demands have many components, sub-systems, and controls. Building construction involves many specialized trades that often work independently of one another which can produce HVAC systems that may not perform properly. Without measurement and verification of the optimum operation of systems, performance will fall far short of design specifications, increasing building operating costs needlessly while wasting energy.

Alnor products are ideal for commissioning projects since they are portable and have datalogging capabilities, making it easy to document system performance on a regular basis. Alnor test instruments are available for many different measurement applications and are designed to save money and minimize testing time. These tools can quickly pay for themselves when properly used to measure, diagnose, and correct building HVAC system performance. In addition, these tools can be used to periodically spot-check systems to confirm efficient and economical operation as part of a building-wide, systematic, preventative maintenance program.

TAB: Testing, Adjusting, and Balancing

Testing, adjusting, and balancing (TAB) are specific steps and processes that typically consist of setting volumes (flow), temperatures, pressures, velocities (speed); recording data; making tests; and preparing reports. These activities are performed on building environmental systems including, but not limited to, air distribution systems, hydronic distribution systems, and the equipment and apparatus interconnected to these systems.

All test instruments used for measurement must be accurate and calibration histories for each instrument must be available for examination. Calibration and maintenance of all instruments must be in accordance with the requirements of the applicable TAB certification agency affiliated with the TAB firm performing the work.

Testing—the use of dedicated instruments to measure rotational speed, temperature, pressure, noise level, velocity, and volumetric flow rates to evaluate mechanical equipment and system performance.

Adjusting—the final set point of control or balancing devices such as dampers, valves, thermostats, pressure controllers, pumps, and computer controls.

Balancing—the regulation of air or water system flows through the use of acceptable industry procedures to achieve the designed flow in cubic feet per minute (cfm), gallons per minute (gpm), and air changes per hour (ACH).

HVAC systems initially installed in a building will usually not function at design specifications automatically upon startup. Adjusting a system to function at design conditions requires testing, adjusting and balancing of control devices. Testing, adjusting, and balancing (TAB) is the method used to calibrate the environmental settings within the building. Some of the main goals of TAB include the following:

- Satisfying the occupants' comfort.
- Achieving the conditions of the HVAC system design specifications.
- Extending maintenance intervals and equipment life.
- Meeting energy conservation requirements.
- Operating in an efficient and economical manner.

Many existing buildings have experienced some type of change from their original design. Examples include renovation work, new construction, and activities which may be drastically different from the original intended usage. In these cases, new testing and balancing is critical to ensure maximum operating efficiency while providing comfort to the occupants. Some buildings also may require balancing throughout the year as the system switches from heating to cooling mode and vice versa.

Certification and Clean-air Measurements

Monitoring air conditions is a major concern in clean environments since they need to meet more stringent requirements. Air measurement verification has become mandatory for many laboratories and facilities, and can be subject to government regulation and inspection.

For critical electronic component manufacturing, food and beverage processing, pharmaceutical production, and other critical environments, quality of ambient air can directly impact product quality and economic bottom line.

Laboratory fume hoods, biological safety cabinets, industrial hoods, and spray-paint booths are typical applications where measuring and maintaining proper air velocities are critical to safe, healthy working conditions. Beyond the need for human comfort and safety, exposure to dangerous, infectious or contagious material must be controlled. Ventilation and correct air flow distribution are vital to maintaining product quality and yield.

IAQ

Indoor Air Quality is another significant factor that may impact occupant comfort-productivity-health, product quality, and in some cases affect building structural integrity. Indoor Air Quality encompasses a number of air parameters including, but not limited to, relative humidity, temperature, air circulation, outside air concentration, volatile organic compound concentration, and fume/vapor dispersal.

Humidity should be periodically monitored to ensure it stays between 20 and 60 percent, the generally accepted ASHRAE guidelines. CO₂ levels are an important indicator of indoor air quality. Elevated CO₂ levels can be indicative of inadequate ventilation which can also increase the levels of volatile organic compounds which may affect the health and safety of building occupants.

There are a number of instruments on the market today that accurately measure humidity and CO₂ levels. Many incorporate multiple air measurement parameters, maximizing their value and minimizing the impact on your equipment budget.

Combustion Analysis

Combustion occurs when fossil fuels, such as natural gas, fuel oil, coal or gasoline, react with oxygen in the air to produce heat. The heat from burning fossil fuels is used for industrial processes, environmental heating or to expand gases in a cylinder and push a piston. Boilers, furnaces and engines are important users of fossil fuels.

Fossil fuels are hydrocarbons composed of primarily carbon and hydrogen. When fossil fuels are burned, carbon dioxide (CO₂) and water (H₂O) are the principle byproducts formed from the carbon and hydrogen in the fuel and oxygen (O₂) in the air.

Combustion analysis is part of a process intended to improve fuel economy, reduce undesirable exhaust emissions and improve the safety of fuel burning equipment. Combustion analysis begins with the measurement of flue gas concentrations and gas temperature, and may include the measurement of draft pressure and soot level.

The purpose of this handbook is to inform readers of the variety of instrumentation technologies available for ventilation and hydronic testing and which instruments are best suited for a particular measurement application. Since no one product is suited for every type of job, it is important to carefully analyze the measurement requirements and select an instrument that best suits the particular application.

Measurement Instrumentation

Capture Hoods

The volume of air emerging from grilles and diffusers is a critical measurement in HVAC systems. Such measurements were traditionally taken using a deflecting vane anemometer with a diffuser probe and applying the diffuser manufacturer's "A_k" factors. Capture hoods have replaced the deflecting vane anemometer with diffuser probes due to their ease of use, quick measurements, and near elimination of the need to apply grille manufacturers "A_k" factors. It still may be necessary, however, to develop a correction factor to apply to the measured reading to compensate for the varying duct and diffuser outlets encountered in the field (see Appendix C). Primary benefits for air balancing using capture hoods include one-step direct volume measurement, time savings, ease of use, and convenience.

Capture hoods can be configured with various sizes of fabric skirts and frame supports to fit different diffuser and grille configurations. The hood "captures" all air exiting from a diffuser or grille and guides it through a sampling manifold which has evenly spaced inlets to average the flow through the manifold. These instruments are used on both supply and exhaust outlets with separate calibrations for each mode performed at the factory.

Mechanical (Analog) Capture Hoods

With a mechanical capture hood, air flows from the sensing manifold through a mechanical, user adjustable, range selector and finally to a deflecting vane anemometer that reads directly in cubic feet per minute. Analog models require no batteries or power supply and can be used on ceiling, sidewall, and floor outlets. When using an analog capture hood, verify the unit is reading zero in the position it is to be used. The zero adjustment screw can be used to adjust the pointer on the meter to read zero in any position.

- Interchangeable hoods mount directly to the base which contains the averaging manifold, range selector, and meter.
- Hoods are available in many different sizes to accommodate a variety of applications.
- Many hoods incorporate a selection knob to select both flow direction and range, allowing the full-size mechanical hoods to measure supply or return diffusers on various ranges.
- A low flow adapter screen attached to the base of the mechanical hood allows measurements with better resolution on systems which incorporate low volume diffusers.
- Hoods have a zero adjustment screw on meter assembly.
- They use a swinging vane, pressure-based sensing method.



Balometer Sr.



Balometer Jr.

Smaller, more compact analog models are available with varying hood sizes. The lower profile hoods are useful in tight quarters such as over filing cabinets, heavy equipment, and office partitions as well as for residential applications.

- Interchangeable hoods mount directly to the base which contains the averaging manifold, range selector and meter.
- Hoods may incorporate a selection knob to select both flow direction and range, allowing the mechanical hood to measure either supply or return diffusers.
- A low flow adapter screen attached to the base of the mechanical hood allows measurements with better resolution on systems which incorporate low volume diffusers.
- Hoods have a zero adjustment screw on meter assembly.
- They use a swinging vane, pressure based sensing method.

Digital Capture Hoods

Digital capture hoods operate under the same basic principle using skirts, frames, and averaging grids. However the sensing technology is different. Instead of having the mechanical range selector, most digital hoods are auto ranging. The sensors used to measure the flow through the manifold can be a thermo-anemometer (hot wire) sensor or a pressure sensor. The hot wire format provides a quick response and continuous readout on the LCD display. Pressure sensor-based capture hoods commonly contain zeroing valves which automatically zero the pressure sensor during normal operation. Digital hoods display standard air volume rate when placed at supply or return diffusers, registers, or grilles located on the ceiling, wall, or floor.

- Digital capture hoods measure a wide flow range.
- They may sum and average air flow and temperature.
- Many store readings that can be printed during operation to an optional printer or saved for later downloading to a personal computer.
- Some use an adjustable tilt mechanism that allows the user to view the meter display from a wide range of angles.
- On some models, the meter can be disconnected and removed from the base and used with optional temperature, velocity or relative humidity probes.

Small digital capture hoods are available that are mainly used in residential or light commercial applications for taking measurements from 10 to 500 cfm (17 to 850 m³/h). The compact size allows them to be used where full size hoods would not fit. For example, the LoFlo Balometer[®] hood is battery powered and may be used with or without the optional 16 × 16 in. (40.6 × 40.6 cm) and 2 × 2 ft (61 × 61 cm) hoods.

- These hoods may have combination analog/digital displays.
- A vent mechanism reduces the flow restriction caused by the instrument. This venting system allows the instrument to remain compact and still measure a wide range of volume rates.
- These hoods are light-weight.
- They utilize thermo-anemometry sensing technology.



Electronic Balometer using a thermo-anemometer sensor



LoFlo Balometer

Digital Capture Hoods with Differential Pressure Sensor

The same principles, general configuration, and optional hood sizes used on the previous capture hood examples also apply to digital hoods that use a differential pressure manometer and averaging manifold as the display and base sensor.

Pressure based digital hoods are popular with test and balance professionals due to the versatility of the instrument. The meter is a manometer that can be detached from the hood assembly and used with common HVAC pressure-based testing probes such as a pitot tube, velocity matrix, air probe, and static pressure probe. Additional measurements for relative humidity and temperature can be obtained by attaching optional probes to the meter which further enhances the versatility of the instrument. These hoods typically offer the following:

- A wide volume range for supply and exhaust measurements.
- Automatic density correction for temperature and pressure.
- Backpressure compensation.
- An auto-zero feature.
- Tilt and backlit LCD display.
- Datalogging and downloading to a PC.
- Statistics (minimum, maximum, and average).
- Internal charging of NiMH batteries.



EBT721-21 Balometer

Thermo-Anemometers (Hot-Wires)

Thermo-anemometers, also known as “hot wires,” operate on the principle of heat transfer. A sensor is heated above room temperature by passing current through an electrical resistance and the energy is converted to heat. Through convective heat transfer, the heat is transferred to air passing over the heated element. The electronics provide more power to the heated wire to maintain the initial temperature at zero flow, and this increased power curve signal is converted to a velocity reading on the display.

Thermal anemometers accurately measure a wide range of velocities, anywhere from 10 to 10,000 fpm (.05 to 51 m/s). They have small probe diameters which allow them to be placed in tight areas, such as measuring air velocity in between circuit boards in a PC or in small ducts. Thermo-anemometers have air temperature limitations. Most units have a maximum temperature of approximately 180 to 200°F (82 to 93°C), which generally limits their use to ambient conditions.

Thermo-anemometers are commonly used to measure velocity in paint spray booths, laminar flow hoods, air flow system balancing and duct traverses, pharmaceutical manufacturing areas, clean-room biological safety cabinets and fume hood testing, room air currents, and draft measurements.

Basic Thermo-Anemometers

These small, compact models are useful for general air velocity measurements. Velocity ranges are typically less than 4000 fpm (20 m/s) and temperature measurement capability along with a telescopic probe may be available on some models. Most models offer the following:

- Low cost instruments with good accuracy.
- Available with a digital LCD or analog meter readout.
- Available as intrinsically safe models.
- Available in English or metric models.



Model 9870

Thermo-Anemometers with Mathematical Calculations

These models are commonly used to perform duct traverses and face velocity measurements of fume hoods and HEPA filters due to their ability to take multiple measurements and to average the readings. Optional portable printers can be used with these instruments to print test data in real time. They usually provide the following:

- Wide velocity and temperature range.
- Velocity to volume flow conversion based on duct dimensions.
- Telescopic or straight telescopic probes.
- User-adjustable dampening or time response settings.
- English or metric readout capability.



CompuFlow 8570

Comprehensive Thermo-Anemometers

These models provide the same accurate velocity and temperature measurements as the other models. Additional functions include humidity measurement in %RH and conversions to wet bulb and dewpoint temperatures. A data logging function allows the user to program the number of samples to be taken and the time interval between samples. This can be a very useful feature when tracking trends over a period of time. These meters offer the following:

- Segregate data groups in separate test IDs.
- Recall stored data on instrument display.
- Download stored information to a PC or portable printer.
- Offer telescopic or straight telescopic probes.
- Perform density correction.
- Have backlit LCD display.



CompuFlow 8585


Rotating Vane Anemometers

A rotating vane anemometer is similar to a small windmill where airflow impinges on the vane creating rotation. It is useful for measuring air velocity at supply openings, but not for multiple throw diffusers. A characteristic of the rotating vane anemometer is its ability to average air velocities over an area. It is most commonly manufactured in four-inch-diameter versions which generally prevents its use for measuring duct velocity. However, it has been found useful in walk-in ducts and on large filter banks.

Like most air measuring instruments, the rotating vane anemometer is subject to errors due to angle of attack, but these errors are small. A one percent error is typical for ± 12 degrees. These instruments read in actual feet of air at its existing density which results in actual fpm (m/s). If standard fpm (m/s) is desired, simply multiply the anemometer reading by the actual density divided by standard density. The rotating vane anemometer must be handled with care, since it cannot survive rough treatment. Likewise, it should not be used in dusty or corrosive environments.

Mechanical Rotating Vanes

The mechanical rotating vane anemometer incorporates a revolution counter that is engineered and calibrated to read air velocity directly in feet of air. To use this instrument, hold it directly in the air stream, permitting the rotating blades to get up to speed, then start the counter and let it run for a specific amount of time (at least 30 seconds) as timed by a watch which accurately indicates time in seconds. The “feet of air” (“meters of air”) reading on the dial, divided by the time in minutes, gives the average velocity in fpm (m/s).



Mechanical Rotating Vane

Digital Rotating Vanes

Electronic versions of the rotating vane anemometer are prevalent today. The fan blade rotation is sensed by a magnetic or optical pickup and the signal is converted to a direct fpm velocity readout. Digital models have less bearing friction than mechanical vanes, allowing for accurate measurement from 50 to 6000 fpm (0.25 to 30.5 m/s). A directional arrow located on the vane head identifies the flow direction used during factory calibration and should always be pointed in the direction the airflow is traveling when used in field applications.

Handheld models may incorporate a user-adjustable, swivel head, which can be used for taking readings in supply or exhaust openings while allowing the operator to view the display regardless of flow direction. Models with telescopic, articulated probe assemblies allow for a longer reach for measuring air flow in a hard to reach area such as a return grille mounted on a wall or above filing cabinets. They also offer the following:

- Minimum, maximum, and averaging capabilities.
- Air temperature measurement.
- Direct conversions to cfm or m^3/h by inputting the free area in square feet into the instrument.
- Data logging and memory storage functions for higher end models to enable later data recall or downloading to a PC or portable printer.



RVA+




RVD

Deflecting Vane (Swinging Vane) Anemometers

The deflecting vane anemometer is a mechanical instrument based on technology developed in the 1930s and is still widely used in the field today due to its ease of use, portability, direct readings in velocity units, and ability to operate with no batteries or power supply.

The moving element consists of a pointer and a vane mounted on a taut-band suspension. This allows the vane to swing inside an air chamber and its movement is virtually friction-free. The flow through the instrument is created by the velocity pressure at the point being measured, which is converted to readout in actual fpm (m/s). Like other mechanical instruments, it should be handled with care.



Cut away view of the deflecting vane and tunnel assembly

6000AP Velometer

This instrument is available in a kit that includes various probes and accessories. The probes plug into a range selector which allows the use of a velocity or static pressure probe appropriate for the application. The range selector incorporates two calibrating restrictors, making it possible to quickly switch from one range to the other. The deflecting vane anemometer is readily portable and can be held in any position for reading convenience, but the system is designed for two-handed use. The probe accessories include:

- Low flow probes that measure velocity from 50 to 300 fpm (0.25 to 1.5 m/s).
- A diffuser probe for measuring outlets using diffuser and grill manufacturers “A_k” factors.
- A pitot tube used for duct traversing.
- Two static pressure probes for 0 to 1 in. H₂O (0 to 250 Pa) and 0 to 10 in. H₂O (0 to 2500 Pa) ranges.



6000AP Velometer

Velometer Jr

The deflecting vane anemometer is also available in a smaller hand-held size intended to be placed directly in the air stream. Its compact size makes it convenient for measuring airflows at registers, fume hoods, doorways, and at spray booths and refrigerated display cases commonly found in grocery stores.



Velometer Jr

Manometers

Taking pressure measurements in HVAC systems has been a standard method of checking system performance in mechanically ventilated buildings for many years. Manometers are instruments used to measure low pressures, such as duct static pressures and differential pressures, across filters or between rooms. When connected to a pitot tube, velocity pressures can be measured in ducts and then converted to velocity or volume units of measure.

Inclined Gauge Manometer

The traditional method of measuring pressure is to use a liquid manometer known as an inclined gauge or incline manometer. To get a good set of readings in the field, the instrument must be properly positioned (mounted on a wall, duct, or set on a steady table) and leveled carefully. It also must be zeroed and all of the bubbles in the liquid removed. Attaching, leveling, and zeroing must be done at each location where measurements are taken.



Incline Manometer

Digital Micromanometer

The most popular type of manometer today is a digital micromanometer. Like a liquid manometer, this instrument is a differential pressure measuring device. It can be used with any standard pitot tube to measure static pressure, velocity, or volume. A digital micromanometer can be used in any position and does not require leveling. However, it should be zeroed periodically throughout a workday.

Most digital micromanometers measure pressure and velocity in English or metric modes and include averaging capability. High end units can directly measure flow in cfm (cubic feet per minute) or m^3/h (cubic meters per hour) by inputting duct dimensions for round or rectangular configurations. They also offer:

- Data logging or memory storage for later data recall.
- The ability to download stored data to a PC or printer.
- Adjustable dampening or time response settings.
- Density correction for temperature and barometric pressure to compensate for elevated temperatures and altitude.



AXD 560 Micromanometer with Pitot Tube

Digital Auto-Zeroing Micromanometer

Auto-zeroing micromanometers are similar to standard digital micromanometers in that they do not require any kind of leveling and are not position sensitive. However, micromanometers with an auto-zeroing function along with a high resolution pressure sensor measure lower pressures and velocities with higher accuracy than standard digital micromanometers. This allows them to be used with a variety of different pressure based probes in addition to the standard pitot probe. Auto-zero micromanometers provide the following:

- Pressure, velocity, and volume measurements.
- Automatic density correction for temperature and pressure.
- A tilt and a backlit LCD display.
- Datalogging and downloading to a PC.
- Statistics (minimum, maximum, and average).
- Internal charging of NiMH batteries.
- Optional probes include pitot probe, air probe, velocity matrix, static pressure probes, relative humidity and temperature probe.



EBT720 Micromanometer shown with velocity matrix, air probe, pitot probe, temperature probe, and relative humidity/temperature probe

Pitot Tube

Pitot tubes are used with manometers to sense total and static pressures in ducts and plenums. The pitot tube is a simple, rugged probe and, if properly constructed, requires no calibration. However, it must be properly maintained. A small buildup of dirt around the static holes can cause instrument errors in both directions. Small leaks in the tubing connection or the tube itself can also cause substantial errors.

Pitot tubes are double-walled tubes typically fabricated from stainless steel. The inner tube senses the total pressure, and the outer tube senses the static pressure. The difference between the total pressure and the static pressure is referred to as the *velocity pressure*, which can be converted to velocity in fpm (m/s). Measuring velocity pressure using a pitot tube is accomplished by connecting rubber hoses from the total and static pressure legs of the pitot tube, to the positive and negative ports of the manometer, respectively.

- Total Pressure (P_t): the sum of the impact caused by velocity pressure plus static pressure in the duct
- Static Pressure (P_s): exerted equally in all directions
- Velocity Pressure (P_v): the pressure required to accelerate the air stream to its velocity, determined by subtracting static pressure from total pressure

$$P_v = P_t - P_s.$$


Standard equations can be used to convert velocity pressure to velocity (fpm or m/s) by taking into consideration both air density and humidity. Once the velocity pressure is known, the following formula can be used to convert to velocity:

$$\text{fpm} = 4005 \times \sqrt{\Delta P} \quad \Delta P = P_v \text{ or differential pressure in inches H}_2\text{O}$$

or

$$\text{m/s} = 1.29 \times \sqrt{\Delta P} \quad \Delta P = P_v \text{ or differential pressure in Pa}$$

The pitot tube is subject to error due to the angle of attack and yaw, so its use is generally limited to reading velocities inside ducts, where the direction of air flow is relatively well controlled. It is usually not a good choice for taking readings at supply openings because of the drastic changes in air flow direction at, or immediately ahead of, the opening. In general, it is not appropriate for measurements at an exhaust opening or in an open space. The stainless steel construction allows it to be used to measure air velocities with high temperature applications. Stacks, flues, chimneys or other combustion processes are a few examples of measuring air flows at elevated temperatures.




Hydronics

Hydronic systems found in HVAC configurations primarily use hot and chilled water as the means for heat transfer. The hydronic system must be able to efficiently distribute water to all terminal devices under design load and part load conditions to be considered operating properly. If the system is not balanced for design conditions, then the cost to operate the system will be higher than anticipated.

Correctly balancing a hydronic system requires the proper tools and procedures. Manual balancing valves installed in the system are typically used to regulate flow to all points to achieve design conditions. Flow control through the balancing valve is accomplished by adjusting a valve to vary the differential pressure across it.


Hydronic manometers or pressure gauges can be connected to pressure taps on the balancing valves to measure the differential pressure across the valve, which then can be used to determine flow. The flow-rate is determined by taking the differential pressure reading across the manual balancing valve and applying it to a *pressure versus valve setting* chart (developed by the valve manufacturer).



Example of a conversion chart for a balancing valve

Mechanical Gauges

Mechanical gauges are simple devices, available in various scales and measurement units. If certain applications require readings in PSI, ft H₂O, in. H₂O with varying ranges (0 to 25, 0 to 50, 0 to 100, etc.), then several different models would be utilized to maximize resolution and accuracy. Common refrigeration hoses with Schraeder-type fittings are typically used with these gauges.




Mechanical gauge with hoses

Digital Hydronic Manometers

Digital hydronic manometers have features such as multiple units of measurement in English or metric, wider ranges with good accuracy and resolution, and large LCD displays. A single unit replaces multiple mechanical gauges. Digital models require a power source such as a plug-in AC power supply, disposable alkaline batteries, or rechargeable batteries with separate charging station. Standard refrigeration grade hoses and fittings with shut off valves are also used with digital models.

- These units have a backlit display for poorly lit areas.
- They offer memory, recall, datalogging, and downloading functions.
- They accommodate an optional portable printer.
- They have user-adjustable dampening or time response settings.
- Some hydronic meters also perform flow and other calculations.



Hydronic Manometer measuring the pressure rise across a pump



HM680 with hoses

IAQ: Ventilation and Carbon Dioxide

A good indicator of proper ventilation is the level of CO₂ present in a space. Carbon dioxide is a normal byproduct of respiration, combustion and other processes. Elevated levels of CO₂ may indicate that additional ventilation is required. Higher CO₂ levels may also indicate more investigation is required regarding ventilation, thermal comfort, or source control. Inadequate ventilation can increase volatile organic compound levels in the ambient air which can affect occupant comfort and health.

The measurement of carbon dioxide concentration relies on one of the natural properties of CO₂ molecules: they absorb light at a specific wavelength of 4.26 μm, a wavelength in the infrared (IR) range. High concentrations of CO₂ molecules absorb more light than low concentrations. The technique used to measure CO₂ in handheld instrumentation is called non-dispersive infrared (NDIR) detection.

Basic CO₂ Instrumentation

These handheld meters measure CO₂ only and displays in units of parts per million (ppm). An NDIR sensor in the top end of the meter measures gas content by diffusion through sensing holes. Basic Alnor CO₂ meters have the following features:

- Measure 0 to 5000 ppm.
- Are capable of sampling data over a period of time.
- Recall minimum, maximum, and average along with sample time in seconds.
- Come with an optional AC power supply.
- Offer a field calibration capability.



Model 8610 CO₂ Meter

CO₂ and Comfort Instrumentation

These handheld instruments can measure CO₂ in ppm along with air temperature, relative humidity, wet bulb, and dewpoint temperatures. The sensors, located in the probe assembly, allow measurement of all parameters simultaneously when the probe is placed in an air-stream within a duct or in an open environment.

These units feature configurable datalogging functions which allow the user to input the number of samples to be taken and the time interval between samples. Separate test IDs can be assigned to data groups, a useful feature for organizing data taken in different areas at various times and dates.

- Optional air or surface temperature RTD probes can be attached to the instrument.
- They compute the percentage of outdoor air based on temperature or CO₂ measurements.
- They provide statistics, memory storage, and recall capabilities.
- Stored data can be downloaded from the instrument to a portable printer or to a PC using CompuDat™ downloading software with the data time and date stamp.
- An AC power supply can be connected to the meter to bypass the batteries and run directly from a wall outlet, useful for tracking trends or changes over time.



Model 8650 CO₂, Temperature and Humidity Datalogger

Thermo-Hygrometers: Temperature and Relative Humidity

Air temperature readings taken periodically in different areas of the building provide an indication of uniformity and consistency of the air temperature. Uneven temperature distribution may indicate problems with the zone controls, reheat coils, or some other mechanical failure.

Low humidity levels in an occupied space may create a dry environment that occupants find uncomfortable. High humidity levels are perceived by many people as being “sticky” and uncomfortable. Elevated humidity levels may also indicate an ongoing moisture problem which can cause damage to building materials due to condensation. Maintaining an elevated humidity level, along with a warm temperature in a dark environment, can promote the growth of unwanted microorganisms.

Thermo-hygrometers are handheld instruments that measure ambient temperature and relative humidity, which are used to verify building HVAC systems, calculate thermal comfort, and investigate IAQ problems in areas such as schools and auditoriums. Common features include internal calculations for converting readings to dewpoint and wetbulb temperatures, field calibration capability, and a dual-line LCD to display temperature and humidity simultaneously.

Basic Thermo-Hygrometers

These thermo-hygrometers are easy to operate and commonly used to perform general data analysis in schools and office buildings. The handheld probe is useful for taking measurements in ducts, through access doors, or at a supply or return outlet. Optional air or surface temperature RTD probes can be attached to the instrument.

- They measure temperature, relative humidity, and dewpoint temperature.
- They are capable of sampling data over a period of time.
- They recall minimum, maximum, and average along with sample time in seconds.



8612 Thermo-Hygrometer

Datalogging Thermo-Hygrometers

These units feature a configurable datalogging function which allows the user to input the number of samples to be taken and the time interval between samples. Separate test IDs can be assigned to data groups, a useful feature for organizing data taken in different areas at various times and dates.

- Optional air or surface temperature RTD probes can be attached to the instrument.
- They compute the percentage of outdoor air based on temperature measurements.
- They provide statistics, memory storage, and recall capabilities.
- Stored data can be downloaded from the instrument to a portable printer or to a PC using CompuDat software with the data time and date stamped.
- An AC power supply can be connected to the meter to bypass the batteries and run directly from a wall outlet, useful for tracking trends or changes over time.



8652 Thermo-Hygrometer

Manual Gas Measurements (Combustion System)

The Orsat analyzer is a gas concentration analysis tool typically used to manually sample CO₂, O₂ and CO from the flue of a combustion system. The Orsat analyzer determines the gas concentrations from a sample of gas extracted from the flue and bubbled through solutions of reagents that selectively absorb each gas. By measuring the decrease in gas volume over the liquid reagents, the amount of gas absorbed is indicated. From this information, stack gas concentration is calculated. Manual gas measurements are time consuming and do not accurately reflect real-time adjustments made to a system.

Portable Electronic Combustion Analysis Instruments

In recent years, electronic instruments such as the Alnor CGA Combustion Analyzer from TSI Incorporated have been developed to analyze combustion byproducts routinely used during tune-ups, maintenance and emissions monitoring. These instruments extract a sample from the stack or flue with a vacuum pump and then analyze the sample using *electrochemical* gas sensors. Thermocouples are used for stack and combustion air temperature measurements, and a pressure transducer is used for the draft measurement. An on-board computer performs the common combustion calculations, eliminating the need to use tables or perform tedious calculations. Electronic instruments show the results of boiler adjustments in real time and give more accurate information to help ensure that a system has been tuned properly.



**Portable Combustion Monitor
Model CGA-823**

Continuous Emission Monitors

Continuous emission monitors, or CEMS, are a class of electronic instruments designed to measure exhaust stack gases and temperature continuously. CEMs are sometimes used for combustion control, but typically are used for monitoring pollutant gas emissions as required by government regulations. CEMs can use both extractive and *in-situ* (sensors in the stack) sampling methods, and employ a variety of electronic sensor technologies for gas detection. CEMs are used most often on larger installations or when required by regulatory agencies.

Measurement Basics

HVAC System Performance

Measuring Air Velocity and Air Volume at Supply Grilles/Diffusers

Supply flow into an occupied space is generally a mixture of return air and fresh outdoor air that has been filtered and then conditioned through heating or cooling coils. This volume of supply air will become entrained with the room air at a known rate in order to achieve occupant comfort by providing sufficient volume flow to satisfy the number of occupants in a given space. The flow rate requirements for a room or building, and the percentage of outdoor air versus return air being delivered will vary depending on the principle purpose of the facility (see *Appendix D, “Determining the Percentage of Outside Air using either Temperature or CO₂ Measurements”* for more information).

It is very important to verify proper manual and automatic control of an HVAC air system. A balanced supply and exhaust will help ensure sufficient ventilation by meeting minimum air exchange rates, removing airborne contaminants which can affect air quality, and reducing operating costs. The supply flow for an area may also affect the room pressurization in relation to an adjacent room or hallway, which can cause drafts or difficulty opening and closing doors.

Capture hoods, rotating vanes, and thermal anemometers are the most common choices used to verify proper minimum flow rates; confirm proper operation of dampers, controls, and fans; and ensure the efficient use of energy.

Capture hoods are popular instruments to use for measuring flow rates from supply grilles. Since they obtain measurements quickly, provide a direct air volume reading, are easy to use, and come with a variety of hood sizes to match various grilles, capture hoods are often the tool of choice (when measuring supply).

ASHRAE recommends performing a duct traverse to determine if a correction factor is needed for air capture hood measurements. Different diffuser styles, elbows attached directly to the diffuser, and dampers located just upstream of the diffuser can impair the uniformity of the flow patterns coming out of the diffuser and affect the hood reading. Be sure to choose the hood size that most closely matches the outlet size being measured. Many capture hoods on the market today include an A_k -factor function.

Utilizing these instruments effectively can help you ensure the proper balance of mechanical HVAC system supply air flows. Additional information can be found in Appendix B, “Flow Resistance,” and Appendix C, “Characterizing a Capture Hood to an Outlet.”



Electronic Balometer measuring a supply diffuser

Nonuniform Flow Corrections

Using a capture hood on a supply opening with no diffuser or deflecting vanes may not provide accurate results due to a nonuniform air pattern and jet effects. Capture hoods are generally calibrated on a wind tunnel with a 2 × 2 ft (61 × 61 cm) hood attached to a diffuser or grille. The diffuser or grille spreads out the air flow and the capture hood will see more uniform flow. Other instruments are often used instead of capture hoods for nonuniform air flow applications.

Other suitable instrument types for this application include rotating vane, thermal anemometer, velocity matrix and swinging-vane anemometers.

Measuring air velocities at a supply opening is easily accomplished when no grille or louvers cover the opening. Divide the opening into sections of equal area (refer to Appendix A) and take a measurement in each section. Instruments used for this application can be a rotating vane anemometer, velocity matrix, deflecting vane anemometer, or thermo-anemometer. Add the readings and divide the sum by the total number of readings to determine the average.

If the supply opening is covered with a simple grille which provides at least 70 percent free opening and there are no turning vanes, a rotating vane anemometer is a common choice. The best procedure is to divide the grille into equal areas and to take a reading at each grille section for at least 30 seconds for a mechanical instrument and 10 to 15 seconds for a digital instrument. The rotating vane anemometer will average the velocity during this timing interval, giving a more stable result. However, the lower the velocity, the longer it may take for the vane to stabilize.

A velocity matrix provides a larger measurement area, reducing the total number of samples resulting in quicker measurements. The velocity matrix can be used on a supply opening with no grill or louvers, but may not be the best choice if there are turbulent air flows. They can cause some turbulent air patterns which could affect the averaging function of the grid pressures.

Many diffuser manufacturers have established A_K -factors and procedures applicable to their outlets for correcting measurements taken with a deflecting vane anemometer equipped with diffuser probe. Probe positioning performed in the same manner as was done in the laboratory is critical in achieving reliable measurements in the field using this technique. The flow rate is determined by multiplying the diffuser manufacturer's A_K -factor by the average velocity in fpm (m/s) to obtain cfm (m³/h).

$$Q = A_K \times V$$

Where:

Q = flow rate in cfm (m³/h)

A_K = outlet manufacturer's correction factor

V = average velocity in fpm (m/s)



Rotating vane measuring an outlet



Diffuser measurement using a diffuser probe and deflecting vane anemometer




Velocity matrix measuring face velocity of an HVAC filter

Since the introduction of the capture hood, the deflecting vane measurement has become less prevalent. It is a good option for low flow applications.

Static Pressure Measurement

Static pressure measurements are an important method of determining system operating efficiency and identifying problems such as leaky ducts, clogged filters and coils, and blocked inlets. Any of these can negatively affect occupant comfort and system operating efficiency which can waste significant utility dollars. Unnecessary increased loads on fans and other system components can cause premature wear and untimely failure, resulting in increased maintenance costs.

Static pressures in air distribution ducts can be measured using a digital micromanometer, incline manometer, or deflecting vane anemometer with static pressure probe. A digital micromanometer or incline manometer can use the standard “L-shaped” pitot probe with a hose connected from the positive port of the manometer to the static pressure leg of the pitot probe. The total pressure leg of the pitot probe and the negative port of the manometer would be open to the atmosphere.



Duct static pressure measurement

Exhaust Grille Measurements

To adequately balance a mechanical HVAC system, it is necessary to also verify exhaust flows. Instruments such as a capture hood, rotating vane, or velocity matrix are common choices to measure exhaust flows.

Capture hoods calibrated for exhaust mode can be used on return grilles without an A_k -factor. For the best accuracy, choose the hood that most closely matches the outlet size being measured and set the hood to exhaust or return mode. Also, as with supply diffusers, an alternate means of measuring flow (such as a duct traverse) is advised when determining if a correction factor needs to be applied to the hood readout.



Balometer measuring a restroom exhaust

For more information, see *Appendix B* on Flow Resistance and how to compensate for this affect. *Appendix C* contains information on Characterizing a Capture Hood to an Outlet.

Rotating vanes can be used on return grilles provided the vanes of the grille are straight with no deflection. Place the rotating vane approximately 1 to 2 inches (2.5 to 50 cm) away from the grille and divide the face of the grille into equal areas (refer to Appendix A) with the vane head taking a measurement in each location. The readings should be added and the sum divided by the total number of readings to obtain an average velocity. The average velocity can be multiplied by the free area of the grille in

square feet (square meters) to obtain a cfm (m³/h) volumetric value. Rotating vanes are a good alternative if the grill is too small or too large to accommodate a capture hood.

A velocity matrix is a good choice for large return grilles with high flow rates that a capture hood cannot accommodate. The face of the return grill should be divided into sections (refer to Appendix A) and the velocity matrix placed in each section to obtain a reading. These readings should be added and then divided by the total number of readings to produce an average velocity. Stand-offs located on the corners of the velocity matrix aid in positioning the matrix for repeatable results by keeping the distance between the matrix and the grill consistent for each measurement.

If the exhaust outlet does not have a grille or louvers, divide the face into a grid pattern with equal areas (refer to Appendix A). A larger number of measurement locations may be required to increase the accuracy of the average flow. Measurements can be taken in the center of each area using a velocity matrix or rotating vane anemometer. However, the blockage effect caused by the size of the instrument when placed in the air stream at the exhaust opening will vary from model to model, and the accuracy may be impaired.

Duct Traversing: Low to High Velocities and at High Air Temperatures

Air velocity measurements are often taken within ducts to determine flow rate. Since velocity distribution is not uniform even in the best of circumstances, a duct traverse is necessary. This involves taking a number of readings within the duct and determining average velocity.

For selecting the most appropriate technique, here are some general guidelines. If air velocity in ducts normally exceeds 1,000 fpm (5 m/s), a manometer with pitot tube, thermo-anemometer, or deflecting vane anemometer with pitot probe can be used for making these measurements. However, each instrument has its limitations and may not be applicable for all jobs.

- If velocities are below 700 fpm (3.5 m/s), the choice of instruments would be between either the deflecting vane anemometer with pitot probe or a thermal anemometer.
- If velocities are below 300 fpm (1.5 m/s), the thermal anemometer may be the only choice. An example is a vertical stack or flue that functions as a result of temperature differences and may contain combustion or industrial process by-products.
- Measuring air flow in extreme air temperatures found in chimneys or drying oven ducts will require a manometer with stainless steel pitot tube that is rated up to 1500°F (815°C).



**Duct traverse with AXD560
Micromanometer and pitot tube**

NOTE: The manometer is not considered to be a flow through device. This means the elevated air temperature seen by the pitot tube will not pass down through the hoses to the manometer and damage components or electronics. However, if the probe is left in the high temperature air-stream for extended periods, high temperatures may eventually affect the tubing connecting the manometer to the pitot tube.

See *Appendix A* for the procedure on how to perform a duct traverse using either a thermo-anemometer, micromanometer with pitot probe, or deflecting vane anemometer with pitot probe.

Measuring Air Velocity in Open Areas


Air velocities (and movement) in a room or space are often felt as a draft and, depending on the intensity, can be uncomfortable to most people. Cross-drafts in areas having spray booths or lab hoods can interfere with air measurement by the permanently installed air velocity monitors on the booth or hood. These and similar situations call for an air velocity measurement in the range of 50 to 200 fpm (0.25 to 1.00 m/s).

- Thermal anemometers are generally the first choice for accuracy, but are inappropriate for determining air flow direction. A smoke source can be used in conjunction with the thermo-anemometer to provide an indication of flow direction.
- A deflecting vane anemometer can also be used in most open areas for measuring velocity. To obtain an accurate reading, hold the instrument in the air stream with the proper port facing upstream. If the flow direction is not known, orient the instrument in various positions until you obtain maximum deflection.
- An air velocity transducer capable of outputting an analog signal (voltage or current) along with an omni-directional thermo-anemometer sensor can be used to measure room currents or draft over a period of time. The analog output signal can be connected to a remote datalogger to track trends in air patterns throughout the day, week, or month in order to get a better understanding of where and when room air currents are unacceptable.

Testing and Certification

Differential Pressure Measurement Between Two Rooms or Areas


Room pressures can be measured using a micromanometer to determine if one room is at a different pressure than an adjacent room or hallway. Isolation rooms in hospitals, for example, maintain a negative pressure differential in relation to an anteroom or corridor in order to contain the spread of infectious or contagious diseases.



To measure the pressure differential from the corridor or anteroom, zero the micromanometer and connect one hose to the *positive* port and run it under a closed door a few feet to the inside of the isolation room or through a port drilled in the wall connecting the two areas. Since the isolation room has a negative pressure, the reading displayed on the micromanometer will be a negative value, giving you the pressure differential between the two areas. The corridor pressure should be at least 0.01 inches of H₂O (2.5 Pa) greater than the pressure of the isolation room.

Spray Booths

There are a number of applications in industrial plants which require air flow measurements at exhaust openings to satisfy minimum requirements for comfort or safety. The most common is a spray booth where the generally acceptable average velocity is 100 fpm (0.51 m/s) and air must be moving *into* the booth at that velocity. An exhaust fan connected to the spray booth duct creates a negative pressure in the booth, resulting in ambient air outside the booth being drawn into the booth to mix with the vapors. The combined air mix then flows up the exhaust duct.



A thermo-anemometer with a telescopic articulated probe, deflecting vane anemometer with a low-flow probe, rotating vane anemometer, or velocity matrix can be used to test spray booths.

- A thermo-anemometer with an averaging feature and datalogging is best suited for this type of measurement.
- The velocity matrix will produce the quickest results.

Laboratory Hoods

Laminar flow benches and laboratory chemical fume hoods typically have average face velocities in the range of 100 to 120 fpm (0.51 to 0.61 m/s) in which no individual face velocity measurement can vary more than 20 percent from the average. This is necessary to ensure the safety of the hood user and to prevent unwanted contaminants from escaping the confines of the hood.


The hood opening is divided into a grid pattern with one square foot sections. The instrument probe is positioned in the center of each section to obtain a reading. When all the measurements have been taken, they are added and divided by the total number of readings to obtain an average velocity. ASHRAE Standard 110 has more detailed information pertaining to the lab hood certification process and should be used as a reference.

A thermo-anemometer with a telescopic articulated probe, deflecting vane anemometer with a low-flow probe, or a rotating vane anemometer can be used for this type of measurement.

- A thermo-anemometer with an averaging feature and datalogging is best suited for this type of measurement during the certification process.
- The velocity matrix will produce the quickest results.

Divide the hood face into a grid with 1 ft² (0.09 m²) sections and take a reading in the center of each.


Add the readings and divide by the total number of readings to obtain the average face velocity.



Unit Ventilators

These are self-contained HVAC systems commonly found in hotels, motels, and schools and used in retrofit situations on older buildings. Measuring the flow rate of a unit ventilator will confirm proper operation for comfort and operating efficiency. Caution is recommended when making the measurements from the outside since wind and cross drafts can affect the accuracy of the instrument readings.


- A capture hood using a 1 × 4 ft (30.5 × 122 cm) or 1 × 5 ft (30.5 × 152 cm) hood will provide a direct volume readout in cfm (m³/h).
- Rotating vane anemometers can also be used to perform this type of measurement. The average velocity measured by the rotating vane can be multiplied by the free area in ft² (m²) to obtain a volumetric cfm (m³/h) result.



Measuring Slot Velocities

Measurements of slot velocities are often required in industrial applications where local exhaust ventilation is required. Examples of this are the ventilating slots at an open plating tank, or the slotted hood over a welding bench. Slot velocities tend to be in the range of 1,500 to 2,500 fpm (7.6 to 12.7 m/s). A thermal anemometer or deflecting vane anemometer equipped with a pitot probe is the best choice for this type of work.

- If multiple measurements are required, a thermal anemometer with datalogging functionality would be the choice.
- Thermal anemometers have a small probe diameter, which is useful on small suction openings. However, this does not mitigate the variable direction of flow in front of the opening, nor does it eliminate the problem of translating fpm (m/s) to cfm (m³/h) in the rapidly changing cross-sectional area of the air stream.
- The deflecting vane anemometer will provide a quick trend analysis of high and low velocity points across the plane of air flow.
- If greater accuracy is required, locating a suitable measuring station in the ductwork downstream from the slot will be necessary.



Measuring velocities at plating tanks using a deflecting vane anemometer with pitot probe

Clean Room Testing and Certification

A clean room is defined as a work area in which the air quality, temperature and humidity are highly regulated in order to protect sensitive equipment from contamination. Clean rooms are important in the production of silicon chips, hard disk drives, and many other products. The air in a clean room is repeatedly filtered to remove dust particles and other impurities that can damage highly sensitive devices during production.

Regular testing of a clean room facility should be scheduled on a quarterly, semi-annual or annual basis to identify significant changes in efficiency. This will ensure changes are addressed before they become a major source of contamination, affecting productivity. Some of the recommended HVAC testing includes the following:

- Filter velocity and uniformity.
- Differential pressures.
- Temperature and humidity.
- Rebalancing of the supply/return air system.
- Air pressure balancing/rebalancing of critical areas.
- Room air change calculations.

Instrumentation commonly used to perform the above mentioned testing includes air capture hoods, micromanometers with a velocity matrix or pitot probe, thermal anemometers, and hygrometers.

Certification is a sequence of comprehensive tests performed on contamination control equipment to assure top-level efficiency of all units. Refer to applicable regulations, such as NSF49, for more information on clean room certification. Be sure to review any applicable industry and safety requirements to ensure the instruments that you use meet the criteria for certification.

Thermal Comfort and IAQ

Air Temperature Measurement

Measurements should be taken periodically in many areas of a building to ensure air is distributed evenly and temperatures are at desired levels. Air temperature is one of the main air quality components affecting occupant comfort and directly relates to productivity and overall operating costs.

Allow sufficient time for the instrument to capture a “stable” reading when taking temperature measurements within an occupied space. If you move from a hot area to a cold area and quickly take a temperature measurement, the accuracy of the reading may be questionable. Temperature measurements performed in a duct require less time to stabilize due to the air velocity in the duct which accelerates the stabilization process.

- Thermo-hygrometers, thermo-anemometers or glass and alcohol thermometers are commonly used to obtain temperature readings.
- For monitoring temperature over a period of time when investigating complaints that occur on an intermittent basis, a thermo-hygrometer is the best choice. The information logged to memory can then be downloaded for analysis.

Information on determining the percentage of outside air using temperature measurements can be found in *Appendix D*.

Relative Humidity Measurement

Relative humidity also affects occupant comfort, productivity and operating costs. Relative humidity measurements taken in various areas within a building are influenced by outdoor air conditions, human activity, HVAC controls, and other factors. A single indoor measurement might not reflect what is happening in all areas and does not provide a good indication of long-term relative humidity trends.

Measurements should be taken within ductwork as well as in open spaces at varying heights to achieve greater accuracy. When the instrument is moved from one area to another with different ambient conditions, it needs to stabilize for a period of time before taking measurements. Humidity measurements performed in a duct require less time to stabilize due to the air velocity in the duct accelerating the stabilization process.

- High end thermo-anemometers with humidity sensor or thermo-hygrometers with data logging features can be used to monitor temperature or humidity conditions as they change over time. This data can then be downloaded for analysis.

CO₂ Measurements

CO₂ measurements are widely used to gauge the adequacy of the ventilation provided to an occupied space by an HVAC system. High CO₂ levels can be indicative of abnormal levels of VOCs which may affect occupant comfort and health, directly affecting productivity and operating costs. Diagnosing and identifying building ventilation problems can be done by comparing peak CO₂ readings between air handling zones or between rooms.

If the number of occupants in the space is consistent during the day, CO₂ levels will rise in the morning hours, fall during the lunch hour when people leave the area, and then rise again in the afternoon to a peak level. CO₂ measurements should be performed throughout the day to track trends or changes in ventilation. Measurements should be taken in different areas, in different air distribution zones, at varying heights and in both indoor and outdoor areas to ensure that the building is properly ventilated.

- High end IAQ monitors capable of datalogging CO₂ along with temperature and humidity throughout the day or week are important tools for IAQ investigations.
- High end IAQ monitors also are capable of computing the percentage of outside air based on supply, return, and outdoor air CO₂ levels.

Information on determining the percentage of outside air using CO₂ measurements can be found in *Appendix D*.



Taking Gas Samples

Extracting flue gases to measure their concentration is done using a stainless sampling probe inserted through a small hole in the exhaust flue. Probe placement is important, and several factors must be considered when choosing a sampling location.

To get the most accurate measurement, the gas sampling probe must be placed prior to any draft damper or diverter, so that the gases are not diluted and as close to the equipment breach as possible so the gases have not cooled in the flue. If there is a stack economizer or similar device, the measurement should be taken just downstream of the installed device.



The figures below show two examples of recommended insertion points for gas sampling probes.



Flue Gas Sampling Locations

NOTE: Special Care for Emission Gas Measurements

For emission gas measurements, consideration must be given to the fact that as water vapor cools and condenses in the stack, highly soluble NO_2 and SO_2 gases may be scrubbed by dissolving in the water droplets. Sampling must be done prior to condensation.


Condensation is a problem in the gas sample line as well as in the flue, causing a loss of NO_2 and SO_2 . Measurement errors due to the loss of SO_2 and NO_2 are lessened by reducing the time water and gases are in contact, and by reducing the contact surface area between the water and gases. This is achieved by quickly removing moisture from the gas sample. If necessary, the use of an ice bath or Peltier cooler, followed by immediate collection of the condensed water in a reservoir separate from the gas stream is beneficial. In addition, when sampling SO_2 and NO_2 , use of a non-reactive, non-wetting material such as Teflon for the sample tubing is essential. Wetting of the interior surfaces, associated with other tubing materials, significantly increases the contact surface area between gas and water, resulting in SO_2 and NO_2 loss via absorption. When a SO_2 or NO_2 gas sample must be transported more than a few feet before the water is removed, the sample lines are usually heated 250 to 300°F (121 to 150°C) to keep water in a vapor state.

Temperature and Draft Measurements

Measurements of the stack gas temperature and the combustion air temperature are required to establish the heat loss from the exhaust gases and determine combustion efficiency. Since stack temperatures can exceed 1,000°F (538°C) a bimetallic thermocouple probe is typically used to measure the stack temperature. This thermocouple probe is placed at the point of highest exhaust gas temperature at

the base of the flue and toward the center for small ducts. If the stack gas temperature is underestimated, the operating efficiency will be overstated. When an economizer or air heater is used, stack temperature is measured after these devices. The figure below shows locations for measuring both stack and combustion air temperatures. Combustion air temperature is measured outside the equipment in these examples.

Draft is a measurement to ensure the combustion gases are being properly exhausted. Draft is measured using a manometer or electronic pressure transducer. The equipment manufacturer can provide the recommended draft pressure for specific equipment and where to take the measurement. Draft is usually measured in the same location as the stack temperature relative to the ambient space. When a draft diverter or draft hood is in the stack, a second measurement should be taken downstream of the device.



Stack Temperature and Combustion Air Temperature Sampling Locations

Soot Measurements

Soot is most commonly measured during equipment tune-up and maintenance by extracting a sample of the exhaust gases using a manual sampling pump. The sample is taken from the same location as the stack temperature measurements shown in figure above. A specific number of strokes on the pump (recommended by the pump manufacturer) are required to draw a known gas volume through a glass fiber filter. Once complete, the filter color is compared to a scale displaying shades of gray corresponding to known soot concentrations.

Appendixes

Appendix A—Performing a Duct Traverse

The following techniques can be used to measure air flow inside ducts using a velocity probe or pitot-static tube. When using a pitot-static tube, the individual velocities must be calculated for each pressure reading and averaged. Averaging pressure with a Pitot tube and then converting into velocity will give an incorrect result, especially if readings are more than ± 25 percent from the average pressure. For a pitot tube, velocity is proportional to the square root of pressure.

Where to Take the Measurement

In order to make air velocity measurements in a duct, it is best to measure at least 7.5 duct diameters downstream and at least 3 duct diameters upstream from any turns or flow obstructions. It is possible to do a traverse as little as 2 duct diameters downstream and 1 duct diameter upstream from obstructions, but measurement accuracy will be affected. When measuring rectangular ducts, use this formula to find the equivalent diameter of the duct when calculating the distance 7.5 diameters downstream and 3 diameters upstream:

$$\text{Equivalent Diameter} = \sqrt{\frac{4HV}{\pi}}$$

Where:

H = horizontal duct dimension

V = vertical duct dimension

$\pi = 3.14$

It is also possible to take a single reading to measure air velocity or air volume flow in a duct, measuring in the center of the duct and multiplying the reading by 0.9 to correct for the higher velocity at the center. If conditions are very good, an accuracy of ± 5 or 10 percent may be obtained this way. This method is not reliable, however, and should only be used where small duct size or other conditions do not permit a full traverse.


Traversing a Round Duct

Using the log-Tchebycheff method, the duct is divided into concentric circles, each containing equal area. An equal number of readings are taken from each circular area, thus obtaining the best average.

- Commonly, three concentric circles (6 measuring points per diameter) are used for ducts of 10 in. (25.4 cm) diameter and smaller.
- Four or five concentric circles (8 or 10 measuring points per diameter) are used for ducts larger than 10 in. (25.4 cm) diameter.

The preferred method is to drill 3 holes in the duct at 60° angles from each other as shown in the following figure. Three traverses are taken across the duct, averaging the velocities obtained at each measuring point. Then the average velocity is multiplied by the duct area to get the flow rate. (An alternative method uses 2 holes at 90° from each other, decreasing the number of traverses with the probe by one.)

Location of measuring points when traversing a round duct using log-Tchebycheff method



Round Duct size	#of Measuring Points Per Diameter	Position Relative to Inner Wall
<10 in. (76 cm)	6	0.032, 0.135, 0.321, 0.679, 0.865, 0.968
10 to 12 in. (76 to 91 cm)	8	0.021, 0.117, 0.184, 0.345, 0.655, 0.816, 0.883, 0.979
>12 in. (91 cm)	10	0.019, 0.077, 0.153, 0.217, 0.361, 0.639, 0.783, 0.847, 0.923, 0.981

Before taking the measurement, multiply the numbers in the table times the duct diameter to get insertion depth for the probe. (Don't forget to use the inside dimension of the duct if it is lined with insulation.)

Example: Using the three-hole, 60-degree method and six measuring points per diameter on an 8 in. (20.32 cm) diameter duct, the following results were obtained:


Insertion Depth	Hole # 1	Hole # 2	Hole # 3
.032 × 8 in. = .256 in. (.032 × 20.32 cm = .650 cm)	843 fpm (4.28 m/s)	857 fpm (4.35 m/s)	822 fpm (4.18 m/s)
.135 × 8 in. = 1.08 in. (.135 × 20.32 cm = 2.74 cm)	912 fpm (4.63 m/s)	929 fpm (4.72 m/s)	891 fpm (4.53 m/s)
.321 × 8 in. = 2.568 in. (.321 × 20.32 cm = 6.52 cm)	977 fpm (4.96 m/s)	993 fpm (5.04 m/s)	971 fpm (4.93 m/s)
.679 × 8 in. = 5.432 in. (.679 × 20.32 cm = 13.8 cm)	1003 fpm (5.1 m/s)	1031 fpm (5.24 m/s)	1018 fpm (5.17 m/s)
.865 × 8 in. = 6.92 in. (.865 × 20.32 cm = 17.6 cm)	922 fpm (4.68 m/s)	935 fpm (4.75 m/s)	912 fpm (4.63 m/s)
.968 × 8 in. = 7.744 in. (.968 × 20.32 cm = 19.7 cm)	869 fpm (4.41 m/s)	876 fpm (4.45 m/s)	861 fpm (4.37 m/s)

Total number of readings: 18
 Sum of all readings: 16,622 fpm (84.42 m/s)
 Average: 923 fpm—16,622/18 (4.69 m/s—84.42/18)

Traversing a Square Duct

Using the log-Tchebycheff method, the duct is divided into rectangular areas, which are further adjusted in size to account for effects of the duct wall on the airflow. A minimum of 25 points must be measured in order to get a good average. The number of data points to be taken along each side of the duct depends on how wide that side of the duct is.

- For duct sides less than 30 inches (76 cm), 5 traversal points must be taken along that side.
- For duct sides of 30 to 36 inches (76 to 91 cm), 6 points must be taken.
- For duct sides greater than 36 inches (91 cm), 7 points must be taken.



Location of measuring points for traversing a rectangular duct using log-Tchebycheff method

Multiply the numbers in the table times the duct dimension to get insertion depth for the probe. For this duct, a 30 to 36 in. (76 to 91 cm) horizontal dimension requires 6 points (or 6 traverse lines). A vertical dimension less than 30 in. (76 cm) requires 5 points (or 5 traverse lines).

Rectangular Duct size	# of Points or Traverse Lines per side	Position Relative to Inner Wall
<30 in. (76 cm)	5	0.074, 0.288, 0.500, 0.712, 0.926
30 to 36 in. (76 to 91 cm)	6	0.061, 0.235, 0.437, 0.563, 0.765, 0.939
>36 in. (91 cm)	7	0.053, 0.203, 0.366, 0.500, 0.634, 0.797, 0.947

Example: The following results were obtained on a 24 by 18 in. (61 by 46 cm) rectangular duct using the five point per side traverse method:

Insertion Depth	Hole # 1	Hole # 2	Hole # 3	Hole # 4	Hole # 5
.074 × 24 in. = 1.776 in. (.074 × 61 cm = 4.5 cm)	929 fpm (4.72 m/s)	903 fpm (4.59 m/s)	941 fpm (4.78 m/s)	911 fpm (4.63 m/s)	918 fpm (4.66 m/s)
.288 × 24 in. = 6.912 in. (.288 × 61 cm = 17.6 cm)	1048 fpm (5.32 m/s)	1064 fpm (5.41 m/s)	1103 fpm (5.60 m/s)	1027 fpm (5.22 m/s)	1033 fpm (5.25 m/s)
.500 × 24 in. = 12 in. (.500 × 61 cm = 30.5 cm)	1067 fpm (5.42 m/s)	1134 fpm (5.76 m/s)	1152 fpm (5.85 m/s)	1121 fpm (5.69 m/s)	1087 fpm (5.52 m/s)
.712 × 24 in. = 17.088 in. (.712 × 61 cm = 43.4 cm)	1104 fpm (5.61 m/s)	1179 fpm (5.99 m/s)	1209 fpm (6.14 m/s)	1182 fpm (6.00 m/s)	1127 fpm (5.73 m/s)
.926 × 24 in. = 22.224 in. (.926 × 61 cm = 56.5 cm)	891 (4.53 m/s)	969 (4.92 m/s)	981 (4.98 m/s)	977 (4.96 m/s)	944 (4.80 m/s)

Total number of readings: 25
 Sum of all readings: 26,001 fpm 132.08 m/s
 Average: 1040 fpm—26,001/25 5.28 m/s (132.08/25)

Appendix B—Capture Hood Flow Resistance

All capture hoods cause flow resistance on the air handling system. Just as different diffuser styles have their own characteristic flow resistance, so do capture hoods. This added resistance reduces the actual volume of air exiting the diffuser. In the majority of cases, this error is less than or equal to the accuracy of the instrument. Proportional balancing techniques will also assist in making these effects negligible.

To determine if flow resistance effects are important, perform duct traverses* to determine the volume rate exiting a diffuser both with and without the capture hood in place. The difference between the volume rate with and without the capture hood in place is the flow resistance effect for that diffuser.

To determine a correction factor for flow resistance that can be used on similar diffusers and duct configurations, use the volume rates as determined from the duct traverses when performed with and without the hood applied to the diffuser or grill as follows.

$$CF = V_{\text{no hood}} / V_{\text{hood}}$$

Where:

- V_{hood} = Flow rate with the hood in place on the diffuser
- $V_{\text{no hood}}$ = Flow rate without the hood in place on the diffuser
- CF = Correction factor

$$V_{\text{corrected}} = CF \times V_{\text{measured}}$$

Where:

- V_{measured} = Volume rate as displayed by the capture hood
- $V_{\text{corrected}}$ = Volume rate corrected for the flow resistance of the capture hood


*Be sure to traverse the duct connected to the diffuser being tested. Also verify that there are no leaks in the duct between the traverse location and the diffuser or in the duct to diffuser connection.

Appendix C—Characterizing a Capture Hood to an Outlet Using a Correction Factor

Alnor Balometer® capture hoods are calibrated on a wind tunnel with a 2 × 2 ft (61 × 61 cm) diffuser for supply and exhaust. To minimize recirculation regions (non-laminar flows on one side of the hood), hood sizes should match the diffuser being measured as closely as possible.


Large recirculation regions will affect volume flow readings. Different diffuser sizes cannot be directly compared. On a 2 × 2 ft (61 × 61 cm) diffuser using a 2 × 2 ft (61 × 61 cm) hood, there are no recirculation regions. If the Balometer hood is used on a small diffuser, the recirculation regions will create turbulence and the accuracy will be impaired. The following numbers are examples of what may happen. Do **NOT** use these numbers as correction factors.

Proper airflow with no recirculation regions



2 × 2 ft (61 × 61 cm) diffuser
 True air flow = 100 ft³/min (170 m³/h)
 Hood air flow = 100 ft³/min (170 m³/h)


Poor airflow with recirculation regions



10 × 10 in. (25 × 25 cm) diffuser
 True air flow = 100 ft³/min (170 m³/h)
 Hood air flow = 90 ft³/min (153 m³/h)


In addition to getting an inaccurate measurement on a 10 × 10 in. (25 × 25 cm) outlet, positioning it differently may give different results.

Balometer centered



10 × 10 in. (25 × 25 cm) diffuser
 True air flow = 100 ft³/min (170 m³/h)
 Hood air flow = 90 ft³/min (153 m³/h)

Balometer NOT centered



10 × 10 in. (25 × 25 cm) diffuser
 True air flow = 100 ft³/min (170 m³/h)
 Hood air flow = 80 ft³/min (136 m³/h)

Characterizing the hood to the outlet being measured is accomplished by performing a duct traverse of the branch leading to the outlet and comparing it to the hood reading. Divide the duct traverse reading by the hood reading to come up with a correction factor to be applied to the hood readout. This correction factor can then be used on similar outlet and duct configurations.

To determine a correction factor for the hood to match a duct traverse, use the following formula:

$$CF = Dtr / Hr$$

Where:

CF = Correction Factor

Dtr = Duct Traverse Reading

Hr = Hood Reading

To apply the correction factor to the hood readout, use the following formula:

$$Hc = Hr \times CF$$

Where:

Hc = Corrected Hood Reading

Hr = Hood Reading

CF = Correction Factor

Appendix D—Determining the Percentage of Outside Air Using Either Temperature or CO₂ Measurements

The introduction of fresh air helps dilute unwanted pollutants and get them out of the building faster. ASHRAE Standard 62 presents recommendations pertaining to ventilation, or the amount of fresh air introduced into a given area. The Standard recommends that indoor CO₂ concentrations not exceed 700 ppm (parts per million) above the outside value. It also recommends a minimum volume of outside air to be supplied to each person over time, depending on the type of space and activity being performed, expressed in cubic feet per minute per person.

The amount of outside air entering the building or an occupied space can be calculated as a percentage of the total air volume. Three measurements need to be taken: supply air, return air and outside air. The supply air must be measured before it enters the room and is diluted. This can be accomplished by placing the probe inside the supply register/diffuser. The return air can be measured at the face of the return grille or inside the return duct. If more than one return, measure at each and sum the results. This calculation can be done using either temperature or CO₂ measurements.

- Using temperature to determine the percentage of outside air is not an ideal method to use in mild climates when the inside and outside temperatures are too close to each other.
- CO₂ measurements should not be used if there are not enough occupants to generate sufficient CO₂.

The equation to determine the percentage of outdoor air is as follows:

$$\text{Percent Outside Air} = \frac{\text{RAM}^* - \text{SAM}^*}{\text{RAM}^* - \text{OAM}^*} \times 100$$

*measurement refers to either CO₂ or temperature

Where:

RAM = Return Air Measure
 SAM = Supply Air Measure
 OAM = Outside Air Measure

The percentage of outdoor air calculated in a ventilation assessment can be multiplied by the volume of air entering a space to determine the amount of fresh air, in cubic feet per minute.

$$\text{Air flow (cfm or m}^3\text{/h)} \times \frac{\% \text{OA}}{100} = \text{OA\% cfm or m}^3\text{/h}$$

Divide this result by the number of occupants to determine the volume of outdoor air per person.

$$\frac{\text{OA\% cfm}}{\# \text{ of people}} = \text{volume of OA per person (in cfm or m}^3\text{/h)}$$

This calculation can be compared to the table in ASHRAE Standard 62 to determine if an adequate amount of outside air per person is being supplied for a particular type of space. The following table lists a few examples taken from Table 2 in the Standard.

Application	cfm/person (outdoor air)
Dinning areas	20
Kitchens	15
Hotel/motel rooms	15
Parking garages	1.5 cfm/ft ²
Office spaces	20
Conference rooms	20
Public rest rooms	50
Smoking areas	60
Retail stores (typical)	15
Gymnasium	20
School classroom	15
School laboratories	20
Auditoriums/theaters	15
Libraries	15
Patient rooms	25
Health procedure & recovery rooms	15
Operating rooms	30
Residential living areas	15
Residential kitchens	25
Residential bath	20
Residential garage	100 cfm/vehicle

Dampers controlling the air intake can be adjusted to allow more or less outside air into the system in order to achieve these target levels.

Appendix E—Air Changes per Hour (ACH)

Air flow can also be used to determine the number of air changes that occur in a space over a period of one hour. This is accomplished by determining the supply cfm (cubic feet per hour) or cmh (cubic meters per hour) and dividing it by the total volume of a space (length \times width \times height) to come up with the number of air exchanges per hour. Likewise, the calculated fresh air percentage can be applied to this air changes calculation to determine changes of fresh air over time in a given space. The exchange of air between inside and outside is important in diluting and removing unwanted contaminants. These calculations are essential to properly maintain a comfortable, safe environment for building occupants, to help optimize the efficiency of the HVAC system, and to control operating costs.

Example:

Total supply air is 225 cfm (382 m³/h)

Total supply air in one hour = 13,500 cfm (225 cfm \times 60 min/hr), (382 m³/h)

Room dimensions are 16 \times 12 \times 8 ft = 1536 ft³ (4.88 \times 3.66 \times 2.44 m = 43.58 m³)

13,500 cfm / 1536 ft³ = 8.78 ACH (382 m³/h/43.58 m³ = 8.77 ACH)


Assume the outside air is 25% of the total volume.

8.78 ACH \times .25 = 2.2 ACH of outside air

Appendix F—Thermal Comfort: Temperature and Humidity

Thermal comfort is a combination of temperature, humidity, air velocity, activity, clothing, and physiology. The main indicators of thermal comfort are temperature and humidity measurements. The recommended temperature range perceived as comfortable is 73 to 79°F (22.7 to 26.1°C) during the summer and 68 to 76°F (20 to 24.4°C) in the winter. Indoor humidity levels should be maintained between 30 to 60 percent for optimum comfort (ASHRAE Standard 55).

ASHRAE Standard 55 links temperature and humidity together to provide a measure of thermal comfort. The objective should be to set the appropriate temperature and humidity levels to maximize occupant comfort and to satisfy at least 80 percent of the occupants while controlling energy consumption. The "comfort zone" shown on the graph is based on the subjective response of people tested under a variety of conditions and their perception of what was or was not comfortable.



Appendix G—Density Correction

Velocity is generally expressed in one of two ways: actual (true) velocity or standard velocity. Actual velocity is the average speed at which the molecules are traveling. Standard velocity is referenced to standard conditions (using a reference of 70°F [21.1°C] and 29.92 in. Hg [101.4 kPa]) and is equal to the actual velocity of the air only when the air is at standard density. The Alnor calibration facilities adjust the actual velocity so that the same number of molecules per unit time are passing over the probe, as if the density were standard density. This makes the instruments display standard velocity.

As a practical matter, many users do not concern themselves with standard versus actual air velocity corrections unless the density of air in their application is more than 10 percent different from standard air density.

Density Correction for Thermo-Anemometers

Thermo-anemometer sensors measure mass air flow velocity which is a measurement of the air mass moving past the sensor and is displayed as standard velocity. Air mass is what gives air its heat holding capacity. Since thermal anemometers measure air mass and display it as standard velocity, many people doing measurements on indoor air are more concerned with standard air velocity.

Standard readings can be converted to actual air velocity to compensate for temperature and barometric pressures. Actual or standard measurements will give the same readings at standard conditions (using a reference of 70°F [21.1°C] and 29.92 in. Hg [101.4 kPa]), but not if pressure or temperature stray from standard conditions.

To calculate actual air velocity, multiply the standard velocity reading indicated by the thermo-anemometer by the following density correction factor:

$$\text{Actual Velocity} = (\text{Standard Velocity}) [(460 + T) / (460 + 70)] \times 29.92 / P_m$$

or

$$\text{Actual Velocity} = (\text{Standard Velocity}) [(273 + T_m) / (273 + 21.1)] \times 101.4 / P$$

Where:

- T = Ambient temperature in degrees Fahrenheit
- P_m = Ambient pressure in inches of Hg.
- T_m = Ambient temperature in degrees Centigrade
- P = Ambient pressure in kPa

Density Correction for Pressure Based Manometers or Deflecting Vane Anemometers

Manometers and deflecting vane anemometers read a nominal velocity that is neither standard nor actual, but a combination of both. This is the velocity read by any Pitot tube and pressure device that does not perform a density correction.

When Bernoulli's equation is applied to the Pitot-static probe, the resultant equation has the form

$\text{fpm} = 4005 \sqrt{\Delta P (\text{in. H}_2\text{O})}$ ($\text{m/s} = 1.29 \sqrt{\Delta P (\text{Pa})}$) when the density of the air is 0.075 lb/ft³ (0.366 kgs/m³). The velocity values displayed by the pressure instrument are the actual velocities *only* if the density where the Pitot probe measurements are being taken is 0.075 lb/ft³ (0.366 kgs/m³). Otherwise, a correction step must be performed to obtain a correct value.

Nominal velocity is a velocity reading that is between actual and standard velocity. It is a good estimation of the actual or standard velocity. Nominal measurements are made using a pitot tube.

Actual velocity is the velocity at which a molecule would be traveling in the air stream.

Standard velocity is the velocity as if the measurement was taken with a thermal anemometer at standard temperature and barometric pressure.

Standard (or mass) velocity in imperial units may be calculated by applying the following formula.

$$V (\text{standard}) = V (\text{displayed}) \times [P(\text{actual}) / P(\text{standard})]^{1/2}$$

Where:

- V (displayed) = Velocity displayed by manometer
- P (standard) = 29.92 in. Hg
- P (actual) = Density of air where the pitot tube is located


Actual (or True) velocity may be calculated by applying the following formula.

$$V (\text{actual}) = V (\text{displayed}) \times [P(\text{standard}) / P(\text{actual})]^{1/2}$$

Where:

- V (displayed) = Velocity displayed by manometer
- P (standard) = 29.92 in. Hg
- P (actual) = Density of air where the pitot tube is located

Altitude versus Barometric Pressure



Note: This chart is intended to give the general indication of pressure at various altitudes when referenced to sea level. This chart does not take into consideration the day-to-day variations of barometric pressure.

In the United States, the barometric pressure reported by the National Weather Service is corrected to sea level and, therefore, cannot be used unless your measurements are taken at sea level. The preferred method is to use the atmospheric pressure at the location of the measurement.

Standard (or mass) velocity in metric units may be calculated by applying the following formula.

$$V (\text{standard}) = V (\text{displayed}) \times [P(\text{actual}) / P(\text{standard})]^{1/2}$$

Where:

- V (displayed) = Velocity displayed by manometer
- P (standard) = 101.4 kPa
- P (actual) = Density of air where the pitot tube is located


Actual (or True) velocity may be calculated by applying the following formula.

$$V (\text{actual}) = V (\text{displayed}) \times [P(\text{standard}) / P(\text{actual})]^{1/2}$$

Where:

- V (displayed) = Velocity displayed by manometer
- P (standard) = 101.4 kPa
- P (actual) = Density of air where the pitot tube is located

Altitude versus Barometric Chart



In the United States, the barometric pressure reported by the National Weather Service is corrected to sea level and, therefore, cannot be used unless your measurements are taken at sea level. The preferred method is to use the atmospheric pressure at the location of the measurement.

Appendix H—Useful Calculations

Total Pressure Formula

Where:

Basic formula: TP (Total Pressure) = VP + SP

Velocity unknown: SP (Static Pressure) = TP - VP

Area unknown: VP (Velocity Pressure) = TP - SP

Converting Velocity Pressure to fpm

For standard air density (.075 lb/ft³ or 1.20 kgs/m³), use formula:

$$\text{fpm} = 4005 \times \sqrt{\text{VP}}$$

$$\text{m/s} = 1.29 \times \sqrt{\text{VP}}$$

For non-standard air density, use formula:

$$\text{fpm} = 1096 \times \sqrt{\text{VP/Density (in. Hg)}}$$

$$\text{m/s} = 1.412 \times \sqrt{\text{VP/Density (kPa)}}$$

Where:

VP = in. H₂O or Pa

Air Flow Formulas

To find the volume of air flowing through ductwork, inlets, outlets, hoods, etc., use the following formula:

Basic formula: Q = AV

Velocity unknown: V = Q/A

Area unknown: A = Q/V

Where:

Q = volume flow rate in cfm (m³/h)

A = area in sq. ft. (m²)

V = velocity in fpm (m/s)

Area Formulas

To determine the area for a rectangular duct:

$$A = L \times W/144$$

$$A = L \times W$$

Where:

$$A = \text{ft}^2$$

L = length in inches

W = width in inches

$$A = \text{ft}^2$$

L = length in feet

W = width in feet

$$A = L \times W/10000$$

$$A = L \times W$$

Where:

$$A = \text{m}^2$$

L = length in centimeters

W = width in centimeters

$$A = \text{m}^2$$

L = length in meters

W = width in meters

To determine the area for round duct:

$$A = \pi r^2/144$$

$$A = \pi r^2/10000$$

$$A = \text{ft}^2$$

$$\pi = 3.14$$

r = radius in inches

$$A = \text{m}^2$$

$$\pi = 3.14$$

r = radius in centimeters

Example: The dimension of a rectangular duct is 24 × 36 in. (61 × 91.4 cm) The average air velocity is 1000 fpm (5.08 m/s). Using the formula for determining the area of a rectangular duct, you will obtain an area of 6 ft² (0.557 m²) Inputting the area into the volume flow formula along with the average velocity, you will obtain 6000 cfm (10196 m³/h).

$$A = L \times W/144$$

$$A = 24 \times 36 \text{ in.}/144$$

$$A = 6 \text{ ft}^2$$

or

$$A = L \times W/10000$$

$$A = 61 \times 91.4 \text{ cm}/10000$$

$$A = 0.55754 \text{ m}^2$$

$$Q = AV$$

$$Q = 6 \text{ ft}^2 \times 1000 \text{ fpm}$$

$$Q = 6000 \text{ cfm}$$

$$Q = AV$$

$$Q = 0.55754 \text{ m}^2 \times 5.08 \text{ m/s}$$

$$Q = 2.8323032 \text{ m}^3/\text{s} \times 60$$

$$Q = 169.93819 \text{ m}^3/\text{min} \times 60$$

$$Q = 10196 \text{ m}^3/\text{h}$$

Subtracting Obstructions From Area

If vanes or bars obstruct the area of air flow, the area of obstruction must be subtracted from the total area. If bars obstruct 0.5 ft² (.0465 m²) of area in the 24 × 36 in. (61 × 91.4 cm) duct:

$$Q = AV$$

$$Q = (6 - 0.5) \text{ ft}^2 \times 1000 \text{ fpm}$$

$$Q = 5500 \text{ cfm}$$

$$Q = AV$$

$$Q = (0.557 - 0.0465) \text{ m}^2 \times 5.08 \text{ m/s} \times 60 \times 60$$

$$Q = 9336 \text{ m}^3/\text{h}$$

Hydronic Equations

$$Q = 500 \times \text{gpm} \times \Delta t$$

$$Q = 4.190 \times \text{l/s} \times \Delta t$$

Where:

Q = heat flow (Btu/hr)
 gpm = gallons per minute
 Δt = temperature difference (°F)

Q = heat flow in watts
 l/s = liters per second
 Δt = temperature different (°C)

$$\Delta P_2 / \Delta P_1 = (\text{gpm}_2 / \text{gpm}_1)^2$$




















$$\Delta P_2 / \Delta P_1 = (\text{l/s}_2 / \text{l/s}_1)^2 \text{ or } \Delta P_2 / \Delta P_1 = (\text{m}^3/\text{h}_2 / \text{m}^3/\text{h}_1)^2$$

Where:


ΔP = pressure difference (psi)
 gpm = gallons per minute

ΔP = pressure difference (kpu)
 m³/h = cubic meters per hour
 ΔP = pressure difference (kPa)
 l/s = liters per second

Appendix I—Common HVAC Blueprint Symbols

UNIT HEATER (PROPELLER) 	UNIT HEATER (CENTRIFUGAL+) 	UNIT VENTILATOR 	THERMOMETER 	DIRECTION OF FLOW 
FLEXIBLE CONNECTION 	DUCTWORK WITH ACCOUSTICAL LINING 	FIRE DAMPER WITH ACCESS DOOR 	MANUAL VOLUME DAMPER 	
AUTOMATIC VOLUME DAMPER 	EXHAUST, RETURN OR OUTSIDE AIR DUCT - SECTION 	SUPPLY DUCT SECTION 	CEILING DIFFUSER SUPPLY OUTLET 	CEILING DIFFUSER SUPPLY OUTLET 
FAN AND MOTOR WITH BELT GUARD 	FLOOR REGISTER 	TURNING VANES 	LOUVER OPENING 	LINEAR DIFFUSER 

Appendix J—Typical HVAC System Showing Some Measurement Locations



Appendix K—Fuel Specifications and Energy Units

Fuel Specifications

Every fuel has a unique composition and energy content described by its fuel specifications. Knowing the fuel specifications is essential for determining combustion parameters such as combustion efficiency, minimum air requirements, CO₂ concentration and emissions factors.

The table below presents fuel specification values for a number of common fossil fuels used in commercial and industrial process boilers and heaters. For some electronic analyzers, like Alnor's CGA series Combustion Analyzers, these values are pre-programmed into the instrument for easy analysis. The fuel specifications are typical fuel values, and may not accurately represent the makeup of the fuel you are presently using. When available, fuel specifications supplied by the fuel vendor should be used.

Specifications	Nat. Gas	Propane	Oil #2	Oil #6	Coal	Wood (dry)	Bagasse	Coke
%Carbon	70.93	81.82	85.84	87.49	94.5	51.8	17.8	98.2
%Hydrogen	23.47	18.18	12.46	9.92	5.2	6.3	2.13	1.5
Btu/lb HHV	21869	21669	19512	18300	13388	9130	4500	16532
Btu/lb LHV	19693	19937	18357	17381	12903	8546	4303	16393
CO ₂ max	11.8	13.8	15.6	16.5	17	19.1	20.6	20.1
%Sulfur	0	0	1.6	1.40	0.034	0	0	0
Moisture	0	0	0	0	0.12	0	63.790	0.5

Fuel Specifications for Selected Fuels

When a hydrocarbon fuel is burned, water is formed from the reaction of oxygen and hydrogen in the fuel. In most cases, this water is in the vapor phase at high temperature and exhausted with the other products of combustion. When exhausted, the heat of vaporization (latent heat) of the water is lost.

Two heating values are typically assigned to fossil fuels depending upon whether the latent heat of the water formed during combustion is included or excluded. If the latent heat of water formation is included, the heating value is referred to as the fuel's *high heating value* or HHV. This is the total fuel energy determined using a *calorimeter*. If the latent heat energy is not included, the fuel's heating value is referred to its *low heating value* or LHV. High and low heating values are both used for calculations of combustion efficiency. Because these heating values can be significantly different, especially for fuels that have a high hydrogen content, it is important to know which heating value is used. Generally, in the United States, the HHV is used whenever efficiency calculations are performed. In Europe, the LHV is often used. Contact your local regulatory agency to determine which value to use.

Energy Units

The common unit of heat measure in the U.S. is the British thermal unit or Btu. One Btu is defined as the amount of heat required to raise one pound of liquid water one degree Fahrenheit, specifically from a temperature of 59 degrees to 60 degrees.

The energy content of a fuel is typically given in Btus per pound of fuel. Fuel oil, for example, has an energy content of roughly 18,500 Btu/lb. For gaseous fuels, such as natural gas or propane, energy content is also expressed in Btus per cubic foot (Btu/ft³). For liquid fuels, such as fuel oil, Btus per gallon (Btu/gal) is commonly used.

When measuring the rate of fuel energy used, the input power or the rate of heat produced, the output power Btus are given per unit time (e.g., Btu/hour). To convert from the rate of fuel used to power, the consumption rate is multiplied by the energy content of the fuel. This calculation is shown in the example below, where ten pounds of fuel with an energy content of 20,000 Btu/lb is burned per hour. The resulting energy consumed is 200,000 Btu per hour.

$$200,000 \text{ Btu/hr} = 10 \text{ pound/hr} \times 20,000 \text{ Btu/pound}$$

Boilers are often rated in “Boiler Horsepower” (BHP) rather than Btus per hour. One boiler horsepower is defined as the amount of energy it takes to convert 34.5 pounds of water to steam in one hour at 212 degrees Fahrenheit. A boiler HP equals 33,472 Btu/hour.

Metric Equivalents

Although common in the United States, the British thermal unit is not used universally. The metric units corresponding to Btus and pounds are kilo-Joules (kJ) and kilograms (kg). The relationships between these measures are:

$$\begin{aligned} 1 \text{ kJ} &= .948 \text{ Btu} \\ 1 \text{ kg} &= 2.204 \text{ pounds} \\ 1 \text{ kJ/kg} &= .429 \text{ Btu/pound} \end{aligned}$$

Appendix L—Sample Boiler Tune-Up Procedure

NOTE: These abbreviated procedures are presented here for illustration purposes only and are not meant to substitute for the actual procedures. When performing tuning or other equipment maintenance, always follow the equipment manufacturer's recommendations. Maintenance, including tune-ups, must always be performed by a qualified technician or engineer.

Tune-up Procedure—Using an Electronic Combustion Analyzer

1. Insert the combustion analyzer gas sampling probe into the flue. The probe should be as close to the equipment breach as possible, upstream of any diverter or draft damper and downstream of the last heat exchanger or heat recovery coil.
2. If ambient air is used as the combustion air, an additional temperature probe is not required. An ambient temperature probe is located inside the Alnor CGA series combustion analyzers.
3. If the combustion air is ducted directly to the combustion chamber or preheated, place a combustion supply air temperature probe into the ductwork just prior to the combustion chamber inlet.
4. Without the gas sampling probe connected to the instrument, turn on the combustion analyzer. Follow the steps on the analyzer to determine if a baseline calibration is required to zero out any sensors that may have drifted from zero. The Alnor CGA series combustion analyzers will give you an alarm message when a baseline calibration is recommended.

Caution—*baseline calibration requires fresh ambient air.*

5. After you have passed or completed a required baseline calibration and there are no errors, the gas sampling probe can be connected to the instrument.
6. Be sure the gas sampling pump is on and all temperature probes are attached. The electronic analyzer is now ready for use to tune the system to optimize combustion efficiency and to monitor any emission gases for which the appropriate sensor is installed in the combustion analyzer.
7. Combustion analysis should be performed on a warmed up unit at firing rates typical of normal operation. For systems with high, low and additional firing rates, adjustments should be made at all firing rates whenever possible.
8. Place the combustion analyzer in a location where the screen is easy to view, free from the modulation controller or linkages to be adjusted.
9. Put the burner control system into manual mode and test several firing rates for combustion efficiency and emission gas concentrations.
 - a. Observe the values on the combustion analyzer. If the percentage of O₂ in the stack is at the lower end of the expected minimum values (as specified by equipment manufacturer) and the CO emissions are low with no smoke being generated, the burner is probably tuned at or near optimum efficiency at this firing rate.
 - b. Observe the values on the combustion analyzer. If the combustion equipment has been tuned previously, compare the previous combustion efficiency to the combustion efficiency of the current measurement. A significant difference indicates burner adjustments or repair might be appropriate to improve combustion efficiency.
10. If tuning the equipment is required, adjust the mechanical linkages to decrease the excess air until CO is about 400 PPM or to the maximum allowable concentration stated in the local code. If a bad flame develops or significant smoking occurs prior to reaching 400 PPM CO, stop making adjustments at this point. This will verify that too much excess air is not lowering efficiency.

11. Observe the O₂ level on the combustion analyzer at these settings. Add oxygen sufficient to satisfy local codes to the observed oxygen level and reset the burner to operate automatically at this higher stack gas oxygen level.
12. Compare the measured value of oxygen at this burner setting to the minimum value of excess oxygen recommended by the local authority. If the minimum value measured is significantly higher than the minimum value recommended by the local authority, then the burner may need additional maintenance or replacement.
13. When an adjustment has been completed, verify the new adjustment has not had an adverse effect on the other firing rates that have already been adjusted. If it has, settings should optimize conditions at the predominant firing rate and the combustion controls need to be readjusted at the affected firing rates.
14. After adjustments have been completed at all firing rates, the controls should be modulated or staged through all combustion firing rates to ensure proper operation. The control settings at firing rates most typical of operation should be recorded. The measurements by the combustion analyzer should be data logged into memory for future reference and for generating printouts and reports.

Additional adjustments may be needed to balance the emissions with the combustion efficiency.

Glossary

Absolute Pressure—pressure above a perfect vacuum; the sum of atmospheric and gauge pressure.

Actual Velocity—the velocity at which a molecule would be traveling in the air stream.

Airflow—the movement of air.

Air Handling Unit (AHU)—includes an air intake, fan (blower), filters, heating and cooling coils, and humidification/dehumidification equipment; conditions the air flow for distribution via ductwork.

Back Pressure—a static pressure increase due to constriction of air flow.

Balancing—adjustment of the HVAC system to ensure operation in accordance with design.

cfh—cubic feet per hour

cfm—cubic feet per minute

cmh—cubic meters per hour

Constant Volume System—the volume of air delivered to an occupied zone by this system does not change, or changes very little. The discharge temperature is controlled in the zone by a temperature controller which activates heating and/or cooling coils.

Diffuser—a square, rectangular, or circular air distribution outlet designed to direct and distribute air in a desired pattern.

Duct Traverse—a method of determining average air velocity in a duct; average velocity can be multiplied by the duct area to calculate air volume or flow rate.

Face Velocity—air velocity perpendicular to a fume hood or spray booth face.

fpm—feet per minute

Gauge Pressure—pressure above atmospheric pressure.

gpm—gallons per minute

Heat Pumps—a type of refrigeration system that draws out heated indoor air in the summer to keep an occupied space cool and removes heat from the cool outdoor air and transfers it to the inside during the winter months.

l/s—liters per second

m/s—meters per second

m³/h—cubic meters per hour

Manometer—an instrument used to measure air pressure.

Multi-zone System—delivers conditioned air to several zones from a single, central air handling unit. The zones served should have similar thermal load requirements such as offices or classrooms. Conditions in each space are maintained by temperature controllers in each zone which vary the amount of heated or cooled air delivered.

Nominal Velocity—a velocity reading that is between actual and standard velocity. It is a good estimation of the actual or standard velocity. Nominal measurements are made using a pitot tube.

Pitot Tube—a small bent tube which measures velocity pressure by means of the differential pressure between total and static pressure.

Return—the half of an HVAC system which exhausts air from various areas of a building back to some type of air handler or out of a building.

Rotating Vane Anemometer—an instrument for measuring air velocity related to revolutions over time.

RTD—resistive temperature detector.

Single-zone System—serves a single, temperature controlled zone. Typically found in small shops or computer rooms where the environment and usage generally remains the same.

Standard Velocity—the velocity measured with a thermal anemometer at standard temperature and barometric pressure.

Static Pressure—pressure exerted by a fluid; total pressure minus velocity pressure.

Supply—the half of an HVAC system which delivers air from some type of air handler to various areas of a building.

Thermal Anemometry—a means of detecting air velocity related to the heat loss of a heated wire or film.

Thermocouple Effect—voltage developed by joining two dissimilar metals to measure temperature differential.

Thermometer—a device used to measure temperature.

Unit Ventilator—single, self-contained system typically found in hotel/motel rooms, schools, garages, and other applications requiring individual room environments to be separately maintained.

VAV (Variable Air Volume) System—air volume to a zone is adjusted via a damper that responds to a zone thermostat controlling heating and cooling coils. VAV boxes can be found on multi-zone system duct runs that are new to the building or are considerably far away from the central air handler unit.

Velocity Pressure—positive pressure caused by moving air; related to air speed squared; total pressure minus static pressure.

References

The following is a partial list of organizations offering information on ventilation:

Air Conditioning Contractors of America (ACCA)—www.acca.org
Air Conditioning and Refrigeration Institute (ARI)—www.ari.org
Air Diffusion Council (ADC)—www.flexibleduct.org
American Board of Industrial Hygienists (ABIH)—www.abih.org
American Indoor Air Quality Council (AmIAQ)—www.iaqcouncil.org
American National Standards Institute (ANSI)—www.ansi.org
American Society of Heating, Refrigeration and Air-Conditioning Engineers (ASHRAE)—
www.ashrae.org
ASHRAE Fundamentals Handbook—www.ashrae.org
ASHRAE Standard 55, Thermal Environmental Conditions for Human Occupancy
ASHRAE Standard 62, Ventilation for Acceptable Air Quality
ASHRAE Standard 111, Practices for Measuring, Testing, Adjusting, and Balancing of Building Heating, Ventilation, Air-Conditioning, and Refrigeration Systems
American Society of Safety Engineers (ASSE)—www.asse.org
Building Owners and Managers Association (BOMA)—www.boma.org
Healthy Buildings International (HBI)—www.hbi.com.au
Indoor Air Quality Association (IAQA)—www.iaqa.org
National Air Filtration Association (NAFA)—www.nafahq.org
National Institute for Occupational Safety and Health (NIOSH)—www.cdc.gov/niosh/homepage.html
National Institutes of Health (NIH)—www.nih.gov
National Safety Council (NSC)—www.nsc.org
The Association of Energy Engineers—www.aee.com
Guide to Energy Management, 2nd edition
Energy Management Handbook, 3rd edition
U.S. Department of Health and Human Services (HHS)—www.hhs.gov
U.S. Department of Labor Occupational Health and Safety Administration (OSHA)—www.osha.gov
National Environmental Balancing Bureau (NEBB)—www.nebb.org
Associated Air Balance Council (AABC)—www.aabchq.com
Sheet Metal and Air Conditioning Contractors National Association (SMACNA)—www.smacna.org
U.S. Environmental Protection Agency (EPA)—www.epa.gov
U.S. Public Health Service (PHS)—www.hhs.gov/phs

A host of trade publications, books and web sites dedicated to ventilation issues also are excellent sources of information but are far too numerous to mention here.



TSI, Alnor Products
500 Cardigan Road
Shoreview, MN 55126-3996 USA
E-mail customerservice@alnor.com
Web www.alnor.com

TSI AB
Lindberghs Gata 9,
195 61 Arlanda Stad, Sweden
Telephone +46 8-595 132 30
Fax +46 8-595 132 39
Email: tsiab@tsi.com

Jan 2004
Printed in U.S.A.
Part # 2980237
© Copyright 2004 TSI Incorporated

FOR MORE INFORMATION CALL ALNOR TOLL-FREE
1.800.424.7427

customerservice@alnor.com

OR PHONE 651.490.2811 FAX 651.490.3824 WEB www.alnor.com]